



NOTE:
 1- INSTALL THE ROOT BARRIER DIRECTLY ON TOP OF WATERPROOFING MEMBRANE.

Xeroflor NORTH AMERICA

WWW.XEROFLORNORTHAMERICA.COM
 TOLL FREE: 1-866-335-1151

XF+GM SYSTEM

Integrated with Irrigation System



SCALE 1:2

©2020