


**NOTE:**  
1- INSTALL THE ROOT BARRIER DIRECTLY ON TOP OF WATERPROOFING MEMBRANE.



WWW.XEROFLORNORTHAMERICA.COM  
TOLL FREE: 1-866-335-1151

## XF+GM SYSTEM

Detail at Roof Parapet



SCALE 1:2

©2020