


NOTE:
1- INSTALL THE ROOT BARRIER DIRECTLY ON TOP OF WATERPROOFING MEMBRANE.

XeroFlor NORTH AMERICA

WWW.XEROFLORNORTHAMERICA.COM
TOLL FREE: 1-866-335-1151

XF+GM SYSTEM

Detail at Vegetation Free Zone



SCALE 1:2

©2020